

pallino

BAMBINI COLLECTION

UNITED COLORS
OF BENETTON.


BAMBINI COLLECTION

Thank you for purchasing a product from the United Colors of Benetton Bambini collection. The UCB Bambini collection is innovative, the design a mix of colour and detail. This collection is for the fashion conscious parent. Parents who enjoy the spirit of colour and the United Colors of Benetton style. The Bambini Collection will show the world how colourful life is with kids!

Produced and distributed under license for Bencom s.r.l. by Born with Style www.bornwithstyle.com.au

Please take a moment to read through these instructions before you use your United Colors of Benetton Stroller.

- Never leave your child unattended while in stroller.
- To prevent choking hazard, remove and discard all packing material before using this product.
- Always use restraint system to keep child from standing up or falling out of the stroller. Use the harness at all times.
- Always balance the weight of the stroller evenly.
- Always lock the stroller open before allowing your child in or near the stroller.
- Only use this stroller with a child weighing less than 20 kg.
- Put on all brakes whenever you park the stroller.
- Never use this stroller on stairways or escalators.
- Do not allow children to stand on seat or sit on footrest.
- This is not an exercise stroller. Do not use product while running, jogging or participating in other athletic activities.
- Do not put child in basket.
- Do not carry extra children or use accessories other than those approved by the manufacturer.
- The stroller should not be used near an open fire or exposed flame.
- Make sure children are clear of any moving parts if you adjust the stroller, otherwise they may be injured.
- Do not put more than 4 kg in the basket.




Stroller Frame



Bumper bar



Canopy



Padded Shoulder Straps




Rear Wheels (2)



Footmuff




Headhugger



Raincover



Bassinet skirt




Canopy skirt




Wrist Strap

- 1 Remove any cardboard inserts or plastic ties used to protect the product during shipment.



- 2 Pull up simultaneously on the two triggers located on the stroller handles as shown.





- 3 Pull up on the handles to begin opening the stroller.



- 4 Push down on the foot lever ensuring that the frame clicks into place.

- 1 Remove and discard protective plastic sleeve from ends of rear axle assembly.




- 2 Position rear wheel on leg of stroller, and push until spring loaded buttons click into place as shown.

- 3 Repeat for second side.


NOTE: If rear wheel assemblies do not click and hold in place. The spring button is stuck and not protruding through the hole in the tube. Use a screwdriver or pliers to move the button so that it protrudes out of the hole in the tube.

TO REMOVE REAR BRAKE ASSEMBLY:
Push in spring buttons on either side of the brake assembly and pull off.




1

ATTACH BUMPER BAR:
Slot the two clips on both ends of the bumper bar into the holes in the frame.




2


REMOVE BUMPER BAR: Press button in (located underneath the frame) and pull the bumper bar off. Repeat for second side.



- 1 Align canopy hook with the stroller frame as shown.



- 2 Push down until the hook clicks into place. Repeat for second side.




1

Place the footmuff over the seat of the stroller with the bottom of the footmuff sitting underneath the leg rest.




2

Pull the top panel over the bumper bar and attach toggles to the elastic. Clip the press studs together at the sides of the stroller.




- 1 Push down release buttons located on both sides of the leg rest simultaneously.




- 2 Pull up the leg rest until it clicks into place. **TO LOWER LEG REST:** Push down on the release buttons and pull the leg rest down.


- 1 Lock foot brake.
Place child in stroller.



- 2 Hook shoulder straps to waist belt.




- 3 To lock harness push the two ends of the straps into the buckle. Be sure both ends are fully inserted. To unlock harness press the tabs together and then slide them from the buckle.




- 4 For proper fit, adjust shoulder straps and waist band as shown.


NOTE: For a secure fit, straps should be at or above the child's shoulder. Adjust straps to higher position as your child grows.



1 Un-hook shoulder strap from waist belt as shown.




2 Pull shoulder strap through the webbing as shown.




3 Hook the shoulder straps to waist belt. Repeat for second strap.


WARNING: To avoid finger entrapment or pinching, take care adjusting the seat back while child is in the stroller. To avoid head entrapment, always fasten the canopy to the seat back at all times.




1 RECLINE SEAT: Pull lever up and pull the seat back.




2 Adjust seat to desired position.



3 RAISE SEAT: Push backrest in an upward direction until it clicks into place.




1 TO LOCK BRAKE: Push down on the brake pedal until it clicks into place.




2 TO UNLOCK BRAKE: Lift up on the brake pedal until it is released.

NOTE: On rough surfaces, lock the wheel to keep straight. On smooth surfaces, unlock to allow the wheel to swivel.




- 1** **TO LOCK FRONT SWIVEL:** Adjust front wheel so that the wheel sits underneath the stroller. Push down on the lock until it clicks into place. Repeat for the second front wheel.




- 2** **TO UNLOCK FRONT SWIVEL:** Push lock up, this will allow the wheel to swivel. Repeat for the second front wheel.


- 1 To fold the stroller remember to lock the brakes, raise the seat, close the canopy and lower the leg rest.



- 2 Pull up simultaneously on the two triggers located on the stroller handles as shown and push down on handles.




- 3 Pull up on the handle located on the back of the stroller as shown until stroller is folded.




- 4 Stroller will automatically lock folded, ensure stroller is locked on both sides as shown.


- 1** Unbuckle harness, remove padded shoulder straps and head hugger.




- 2** Release the velcro on the canopy and then unzip the skirt off the canopy.




- 3** Tilt the canopy over so that it sits on the bumper bar and unclip hidden section of canopy.



- 4** Lift the footrest up to its furthest point.



- 5 Zip bassinet skirt (different piece) onto the canopy and pull the elastic edges over the stroller footrest adjusters.



- 6 Recline the seat making sure that it reclines to the furthest point.

- 7 Adjust canopy to desired position. Pull the harness webbing through to the back of the stroller.

There are hidden pockets in the sides and crutch section. The shoulder harness should be pulled through the back of the stroller and placed in basket until the stroller is used in a forward facing fashion.

- 8 Slip footmuff over the exposed edge of seat for added protection.

There are many ways to look after and protect your United Colors of Benetton stroller. The most important is to clean up any spills or food, before it dries on the fabric.

As the covers are not designed to be easily taken off for washing, (for safety reasons) the easiest method to clean is, sponge the surfaces with a mild solution of warm water liquid laundry detergent. Rinse well with clean sponge and leave to dry out of direct sun.

Sand and salt water should be rinsed with a hose and wiped dry to prolong the life of the wheels, axles and other moving parts.

Never use petroleum based lubricants on your stroller, the most suitable lubricants are silicone based products.

Born With Style warrants this product to be free of defects in materials and workmanship as follows: For a period of ONE YEAR from the date of purchase, Born With Style will repair or replace, at its option, the defective product. This warranty is given in addition to (and not in substitute for) applicable statutory rights which you may have.

We sincerely thank you for purchasing this Born With Style product.

For further information visit:
www.bornwithstyle.com.au

For spare parts, repairs or warranty issues, please contact:

Karlisles

P: 1300 308 435

E: info@karlisles.com.au

W: www.karlisles.com.au

Replacement parts provided by local distributor due to accidental damage or misuse will be charged accordingly.

Born with Style
PO Box 789
Gladesville NSW 1675 Australia

P: 1300 855 337 or 02 9816 3837
E: info@bornwithstyle.com.au
W: www.bornwithstyle.com.au

This product meets and exceeds Australian Standard AS/NZS 2088:2000

Born With Style recommends that you keep a record of important information about your United Colors of Benetton stroller. Please complete the information in the space provided.

Model Number:

Date of Manufacture:

Date of Purchase:

