

Model

Challenger Deluxe

CF3850

Features:

- Lightweight aluminium easy to fold stroller with reversible handle suitable from newborn.
- Four large wheels with a linked steering mechanism for a smooth ride.
- Adjustable layback seat with leg extension and a removable bumper bar for baby's comfort.
- Single-hand release double action locking mechanism for easy operation.
- Linked dual front and rear wheel brakes with foot-operated secondary lock for increased safety.
- European style hood with rear pocket and viewing window.
- Supplied with shopping basket, bootcover and rain cover.
- Complies with the AS/NZS 2088:2000 Australian Safety Standard.

Additional products and accessories available in leading department stores and nursery speciality shops include:-

Cots, Portable Cots, Change Tables, Highchairs, Hook on Highchairs, Safety Gates, Bed Guards, Rockers, Parasoles, Pramettes, Strollers, Walkers, Nappy Bags, Rain Covers and Wooden Cots.

Warranty

The manufacturer warrants this product to be free from defects in material and workmanship under normal use and service following the date of purchase for 12 months. This warranty shall not apply to damage arising from neglect, incorrect assembly, accidental damage to, or misuse of the product.

Due to our continuing programme of development, Childcare reserves the right to alter the specifications, colour or design without further notice.

Due to variations in the style and design of our products, the illustrations used in this instruction manual are generic.

This product is not intended for commercial use.



Childcare Nursery Products Pty Ltd
20-22 Lindaway Place Tullamarine Vic 3043
Phone: 03 9335 2244 Fax: 03 9335 2270
email: sales@childcare-prod.com.au
www.childcareproducts.com.au

Challenger Deluxe

CF3850



Keep this booklet in a safe place for future reference

Note: Colour and features of product may differ from the diagrams shown

www.childcareproducts.com.au

WARNING

- FOLLOW THE MANUFACTURER'S INSTRUCTIONS.
- PUT ON ALL THE BRAKES WHEN EVER YOU PARK THE STROLLER.
- DO NOT LEAVE CHILDREN UNATTENDED.
- DO NOT CARRY EXTRA CHILDREN OR BAGS ON THIS STROLLER.
- MAKE SURE CHILDREN ARE CLEAR OF ANY MOVING PARTS IF YOU ADJUST THE STROLLER OTHERWISE THEY MAY BE

Some Important Don'ts

- Follow the manufacturer's instructions.
- Check that all safety locks are engaged before placing a child in the stroller.
- Always apply all the brakes when parking the stroller.
- Never leave your child unattended.
- Ensure your child is secured with a correctly adjusted safety harness.
- Do not carry extra children or bags on the stroller.
- When making adjustments to the stroller, ensure that your child's body is clear of any moving parts on the stroller.
- Do not allow children to stand on the seat.
- Do not hang bags or goods from the handle as this could cause the stroller to tip over.
- Do not place more than 3kgs in the basket, or 1kg in the hood pocket.
- The weight of the child using this product should not exceed 17kgs.
- Do not use accessories other than those supplied and approved by Childcare Nursery Products.
- Never ride with more than one child in the stroller.
- Promptly replace worn out parts.
- Always use the safety locks.
- Remove the child from stroller before going up or down stairs and escalators.
- Do not lift stroller by the bumper bar.
- To prevent the risk of the stroller catching fire, do not park it near an open fire or a barbecue.
- Retain your warranty and keep your sales receipt to provide proof of purchase.
- Recommended air pressure for pneumatic tyre is 20-25 Psi.
(Challenger Deluxe model #3850 only)

How to Care for your Childcare Stroller

Care and Maintenance

To prolong the life of your nursery product keep it clean and do not leave in direct sunlight for extended periods of time.

Removable fabric covers and trims may be cleaned using warm water and a household soap or mild detergent. Allow it to dry fully, preferably away from the direct sunlight.

Helpful Hints

If the wheels squeak –use silicon based spray ensuring it penetrates the wheel and axle assembly.

When using the stroller at the beach – completely clean your stroller afterwards to remove the sand and salt from the mechanisms and wheel assemblies. Dry thoroughly and lubricate with a silicon based spray.

Do Not Dry Clean or Bleach Your Fabrics.

Do not machine wash, tumble or spin dry your fabrics, unless the care labelling on the product permits these methods.

Non-removable fabrics covers and trims may be cleaned using a damp sponge with soap or mild detergent. Allow it to dry completely before folding or storing it away.

In some climates the covers and trims may be affected by mould and mildew. To help prevent this occurring, do not fold or store the product if it is damp or wet. Always store the product in a well-ventilated area.

Always check parts regularly for tightness of screws, nuts and other fasteners – tighten or replace if required. To maintain the safety of your nursery product, seek prompt repairs for bent, torn, worn or broken parts. Use only those parts and accessories approved by Childcare Nursery Products.

Pram Mode (Mother Facing Baby)

Steering Function in Pram Mode

- To disable the steering function when stroller is in pram mode, press steering lock down with one foot.
- To apply swivel function, lift the steering lock as shown.



Brakes in Pram Mode

- To apply brakes when stroller is in pram mode and steering function is enabled, the brake lever must be lifted with foot.
- Release by pressing down the lever.



Assembly Instructions

To Open the Stroller

- Release folding lock as indicated.
- Lift handle and seat apart until the frame clicks and locks on both sides.
- Ensure the stroller is locked in on both sides before using.



Assemble Front Axle and Wheels

- Turn Stroller over.
- Place front axle onto the frame as shown. Gently push down until it clicks and locks into place on both sides.
- Slide each front wheel onto the axle until wheel clicks into place and is secure.



Assemble Rear Axle and Wheels.

- Place rear axle onto the frame as shown. Gently push down until it clicks and locks into place on both sides.
- Slide each rear wheel onto the axle until wheel clicks into place and is secure.



To Fit and Detach Bumper

Fit Bumper

- To fit bumper, line up ends of bumper and slide on until it clicks into place.



Detach Bumper

- To remove bumper, simultaneously press bumper release buttons on either side of bumper and pull away.



Rain Cover

(CF3850 Indigo Sands)

- Place rain cover over the stroller, positioning holes in rain cover over protruding handle catching lock.
- Fasten velcro on both sides of the stroller.




Brakes in Normal Stroller Mode

- When stroller is in normal mode, apply brake bar by pushing down with foot. Ensure brake is applied when parking stroller.



- In order to lift the stroller with foot in the pram mode, you must turn the wheels around into the trail position by simultaneously pressing levers down on both sides, remove wheels and turn around.



Changing from Normal Stroller Mode to Pram Mode (Mother Facing Baby)

- Lift up both handle reverse levers situated on either side of the handle.
- Lock handle into position.



Note: Although you can use the stroller with handle and wheels in any position we strongly recommend that the front wheels be turned around depending on the position of the handle. When using the stroller in the Pram Mode (Mother facing baby), the linked steering wheels should be positioned so they ‘trail’ behind the stroller (so that the ‘brake’ footplate is on the inside of the wheel axel). When using the stroller in the Normal Stroller Mode the link steering wheels need to be turned around (so that the ‘brake’ footplate is on the outside of the wheel axel).

Normal Stroller Mode (Mother Behind Baby)



Steering Function in Normal Stroller Mode

- To disable the front swivel function when stroller is in normal mode, press steering lock down with one foot.
- To steer the stroller, lift the steering lock with foot as shown.



Operating Instructions

6. Folding the Stroller

- Before folding the stroller, remove bootcover, close the hood, place seat in full layback position and transfer handle to rear (stroller position).
- Simultaneously squeeze lever with thumb and push button on handle as shown in diagram using right hand. Push down on handle to commence folding the unit.
- Once fold has commenced, push down on the lever on the left rear leg of the stroller with foot as shown. Continue to push handle down until the stroller has completed its folding action. The folding lock will automatically engage.



Warning: Seat must be in the fully reclined position before the stroller can be folded.


Restraints

To secure the child in the harness, push buckle **A** and **B** into the buckle housing **C** until the buckle prongs snap into position.

Carefully adjust the waist harness by pulling the slider **D** until the desired length is achieved.

Follow the same procedure to adjust the shoulder strap. To release the buckles, squeeze the top and bottom prongs until the buckle disengages.

Always adjust the harness when changing seating positions.



Warning: Many unrestrained children suffer injuries falling from strollers. Use safety harness at all times.

Opening and Closing the Hood

- To open, spread the hood until it is fully expanded.
- Always ensure the hood is closed before folding stroller.



3. Positioning Backrest.

- To lower the backrest, lift backrest adjusting lever by using thumb and forefinger.
- Lower to desired position.
- To raise, simply push backrest up.



Footrest/Leg Extension Adjustment

To Lower

- Simultaneously press the buttons on either side of the leg extension and the footrest will drop automatically.



To Raise

- Lift the leg extension to a desired position. Locks will automatically engage.

Bootcover

- Raise leg extension, place bootcover over bumper bar, side arms and under the seat.
- Secure top end of bootcover by locating holes and fitting over protruding studs on each side.
- Secure straps to lower leg and



Warning: The bootcover must be removed before folding the stroller.