



WARNING:

**AVOID SERIOUS INJURY FROM FALLING OR SLIDING OUT.
ALWAYS USE THE RESTRAINT SYSTEM.**

Your child's safety depends on you. Proper stroller usage cannot be assured unless you follow these instructions.
DO NOT USE STROLLER UNTIL YOU READ AND FOLLOW THE MANUFACTURER'S INSTRUCTIONS.


IMPORTANT SAFETY INFORMATION:

- **NEVER LEAVE YOUR CHILD UNATTENDED WHILE IN STROLLER.**
Accidents can happen quickly while your back is turned. You must always keep your child in view while your child is in the stroller, even when sleeping. Your child may become tangled in straps or pads and suffocate.
- **Always use restraint system to keep child from standing up or falling out of the stroller. Use this harness at all times.**
- **Do not use any infant car seat with this stroller. Serious injury may occur.**
- **Always balance the weight of the stroller evenly.** To prevent the stroller from becoming unstable or tipping:
 - Do not place parcels or accessory items on the stroller canopy, seat, or over the handle.
 - Do not put more than 5 lbs. (2.27 kg) in the basket (select models).
 - Do not put more than 3 lbs (1.362 kg) in each Saddle Bag (select models).
 - Do not allow children to play with or hang onto the stroller.
- **Always lock the stroller open before allowing your child in or near the stroller.** This prevents injuries caused by the stroller collapsing.
- **Only use this stroller with children who weigh less than 35 lbs. (15.88 kg).** Use by larger children may damage the stroller, or cause a hazardous unstable condition to occur.
- **Only use this stroller when child can sit up unassisted or only use product in recline position (select models).**
- **Put on all brakes whenever you park the stroller, especially on an incline.** This prevents the stroller from rolling away.
- **Never use this stroller on stairways or escalators.**
- **Do not allow child to stand on seat or sit on footrest.**
- **This is not an exercise stroller!** Do not use this product while running, jogging, in-line skating or participating in other athletic activities.
- **Do not put child in basket.**
- **Do not carry extra children or use accessories other than those approved by the vehicle manufacturer.**
- **The stroller should not be used near an open fire or exposed flame.**
- **Make sure children are clear of any moving parts if you adjust the stroller, otherwise they may be injured.**


How to Assemble Your Stroller

1 TO OPEN STROLLER:


Step 1. Release clip on side of stroller.




Step 2. Push front of stroller downward.



Step 3. Press down both folding bars to lock stroller.



Step 4. On canopy models, swing canopy forward over handles.




2 TO ASSEMBLE FRONT WHEELS:


IF STROLLER ARRIVES TO YOU WITH THE WHEELS OFF, FOLLOW THE INSTRUCTIONS BELOW:

Step 1. With tab on wheel unit facing away from stroller, place wheel on stroller until it locks onto stroller.

NOTE: To remove, squeeze tab and pull wheel off.




3 TO ASSEMBLE REAR WHEEL ASSEMBLY:



Step 1. For the right rear wheel assembly, slide wheel onto axle.

Step 2. Slide first washer onto axle.

Step 3. Insert axle with washer and wheel into right rear wheel assembly as shown. Make sure axle is inserted into rear wheel assembly from the inside wheel (Figure A).




Step 4. Slide second washer onto axle.

Step 5. Slide other wheel onto axle.

Step 6. Slide third washer onto axle.

Step 7. Fit straight part of cotter pin through hole on axle (Figure B).

Step 8. Line up tabs in each of the hub caps with slots in the wheel, snap hub caps into place.




Step 9. Repeat for left side.

4 TO ATTACH CUP HOLDER (SELECT MODELS):


Attach cup holder to left handle by lining hole over pin and snap into place.

To clean: Top rack dishwasher safe.



5 TO INSTALL SADDLE BAGS (SELECT MODELS):

Step 1. To install saddle bags, snap both clips around frame of stroller as shown.



WARNING!
DO NOT PUT MORE THAN 3 LBS (1.362 KG) IN EACH SADDLE BAG.

How to Properly Use Your New Stroller

1 TO SECURE CHILD IN STROLLER:

WARNING!
AVOID SERIOUS INJURY FROM FALLING OR SLIDING OUT. USE THIS HARNESS AT ALL TIMES.

Lock all foot brakes to keep stroller from rolling.


Step 1. Place child in stroller.

Step 2. Hook shoulder straps to waist belt.

Step 3. To secure, snap each side of waist belt into buckle.

To release, press tabs and pull apart.

Step 4. For proper fit, adjust shoulder straps and waist band as shown.




Adjust restraint system harness

2 TO OPERATE BRAKES:


Step 1. Push both levers down to lock.

Step 2. Pull both levers up to unlock.



3 FRONT WHEEL SWIVEL OPTION (SELECT MODELS):

Step 1. Rotate latches on front wheels down to unlock and allow the wheels to swivel.




Step 2. Rotate latches up to lock front wheels in the straight position.


NOTE: On rough surfaces, lock the wheels to keep them straight. On smooth surfaces, unlock to allow the wheels to swivel.

4 TO RECLINE SEAT (SELECT MODELS):

Step 1. Unhook clips from both sides of stroller.




Step 2. Attach clips to lower bar.




5 TO ROLL UP SHADE (SELECT MODELS):

Step 1. Roll shade towards canopy.




Step 2. Secure with velcro straps as shown.




6 TO FOLD STROLLER:

Step 1. On canopy models, swing canopy back over handles.




Step 2. Adjust seat to upright position.




Step 3. With foot, slide lower red lever to the left and then push up.


Step 4. Push upper lever pedal down.



Step 5. Push handlebars forward and squeeze stroller together.




Step 6. Lock clip on side of stroller.



CARE / MAINTENANCE

- To keep your stroller running smoothly and avoid squeaking wheels, use a light oil (ie: WD-40, 3-in-1 household oil, or a light silicone base lubricant). It is important to get the oil into the axle and the wheel assembly.
- Clean metal parts with a damp cloth and wipe dry.
- Clean woven fabric or vinyl parts with mild soap and water solution.
- Dry wet stroller with a soft cloth to prevent rusting.
- When storing stroller, never stack other items on top of it; this may damage the stroller.
- Periodically check for worn parts, loose screws, torn materials or stitching.
- Replace any damaged parts immediately.



LIMITED WARRANTY

Jeep® is a registered trademark of DaimlerChrysler Corporation, and is used under license by Kolcraft®. © DaimlerChrysler Corporation 2003
KOLCRAFT® warrants this product to be free of defects in materials and workmanship, as follows: For a period of ONE YEAR from the date of purchase, KOLCRAFT will repair or replace, at its option, the defective product.

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. KOLCRAFT SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT, EXCEPT TO THE EXTENT REQUIRED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE DURATION OF THIS WARRANTY.

Some regions do not allow the exclusion or limitation of warranties set forth above, so the above exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights. We sincerely thank you for your purchase of this KOLCRAFT product.

For further information visit www.kolcraft.com

SERVICE HOTLINE

Attention to manufacturing detail and strict quality control ensures that this product meets the highest standards set by Kolcraft Enterprises, Inc. If you encounter any problems or need assistance please call our Customer Service /Warranty Department.

Please direct any comments or questions to:

Born with Style
PO Box 789
Gladesville NSW 1675
Australia
Phone: 1300 885 337 or 02 9816 3837
Email: warranty@bornwithstyle.com.au

Replacement parts provided by local distributor due to accidental damage or misuse to product will be charged accordingly.

To contact the manufacturer directly:

Kolcraft® Enterprises, Inc. Consumer Service Department
10832 NC Highway 211East
Aberdeen, NC 28315
1-800-453-7673 in U.S. & Canada, 1-910-944-9345 outside U.S. & Canada
Eastern Standard Time, 8 am-5 pm

PERSONAL RECORD CARD

Once in a while, we are less than perfect and one of our products reaches a customer with a problem. In most cases, we can solve your problem with replacement parts. Please contact us before you return one of our products to the store. Once a product is returned, it cannot be resold. The materials and the energy used to make it are wasted.

Please fill in the information in the space provided and attach a copy of your purchase receipt. You will need this information to obtain warranty service.

You can find the Model Number and Date of Manufacture on a sticker located on the rear stroller leg.

MODEL NUMBER: _____

DATE OF MANUFACTURE: _____

DATE OF PURCHASE: _____