

Spare Parts Diagram 105-713_Spare_Parts
2008 Breeze Buggy Anodised



ITEM NO.	DESCRIPTION
1	Foam Handle Cover
2	Single Breeze Adj. Handle Sub Assy
5	Anodised Breeze RH base tube assy
6	Anodised Breeze LH base tube assy
7	Anodised Breeze RH down tube assy
8	Anodised Breeze LH down tube assy
9	Breeze link wire sub assy
10	Breeze seat frame sub assy
11	Anodised handle bottom tube assy
13	Breeze rear axle assy
14	Single Acting Brake Wire (05.04.04)
18	Basket
19	Riserplate Pivot Tube (single)
20	Basket Clip
21	Screen Printed Foot Plate Riser
22	Secondary Lock LH Sub Assy
23	Locking slider RH Sub Assy
24	Footplate - plastic
25	10" Tyre and Tube
26	Break Cog (5 Lug)
27	Breeze QR rear wheel assembly (pneu)
28	Front Wheel Assembly (pneu)
30	Triloc Knob
31	Single Front Axle Shaft
32	Brake Wire Cover

